

HLN6853  
belt clip



PMNN4454  
battery



8505241U11\_LG  
7" antenna



*Shorter, shoulder-mic antennas are not intended for use directly on the portable radio.*

PMMN4045 curly cord microphone



4859974  
leather holster



WPLN4111 IMPRES Charger



RLN4941  
earpiece



## Motorola-Recommended Radio Care

**Alignment** Motorola recommends that the radio should be serviced once a year. This procedure is done to ensure that the radios operate on the correct frequency.

**Cleaning** Remove the battery prior to any cleaning of the radio. Motorola recommends mixing one tablespoon of mild dishwashing detergent to one gallon of water (0.5% solution) to clean the external surfaces of the radio. The solution is to be applied sparingly with a stiff, nonmetallic, short-bristled brush (like a toothbrush), making sure excess detergent does not get entrapped near the connectors, controls or crevices. The radio should be dried thoroughly with a soft, lint-free cloth. If the radio battery contact area has been exposed to water, dry and clean the radio battery contacts before attaching a battery to the radio. If the radio has been exposed to salt water (or salt spray), thoroughly rinse the radio with fresh water. If the radio has been submerged in water, shake the radio briskly so that any water trapped inside the speaker grill and microphone port can be removed. The radio should then be dried per above. Motorola recommends vacuuming the speaker grill to maintain optimal audio performance. Motorola also recommends wearing the radio in a carry case or inside the turnout coat (fire departments) to better protect the radio from prolong exposure to dirt, debris, heat and/or impacts.

