

Panasonic CF-20 Toughbook

Hardware tour // version 10-10-17

Slimmer yet still rugged design



Locking flip-latch / battery & power indicator lights



Right view // serial, ethernet, USB 3.0 ports



Rear view with pull-out handle recessed

no more tough-to-reach ports on the backside



Rear view with handle* pulled out.

*acts as kickstand when fully expanded/locked



Left view

tablet: HDMI, USB 3.0, power port, mic, audio, Ethernet, micro SD



base/keyboard: power, SD card slot, HDMI, USB 2.0, VGA

Open View



Detachable keyboard base



Fn+F1 through Fn+F6

Dimmer
screen


Brighter
screen

Extend
Display to
projector/
monitor

Mute
system
sounds

Reduce
volume

Increase
volume



Fn+F7 through Fn+F9

'Processor Suspend'
puts your computer
to sleep

DISABLED
'Concealed
Mode'

Display battery
status - useful if
your model has
double battery.



Fn+F10 through Fn+F12

'Hibernate'
full shut down keeping
your computer in
current state.

DISABLED
Emergency
Button

Keyboard Brightness
4-press toggle: off,
low, medium, high



Touchpad with left and right click

CAPS lock, num lock, scroll lock light indicators




Tablet/Monitor Buttons

A1 – disabled

A2 – On-screen keyboard



Tablet/Monitor Buttons continued



How to Release the Tablet/Monitor


1. Push lock latch down so that orange is revealed




2. Push release slider to right until it clicks



3. Orange rectangle now appears



4. Raise up tablet with a leftward angle (as shown) until it unseats from the keyboard/base



Protect the exposed metal contacts on bottom of tablet when it's undocked.



View of keyboard/base when tablet is removed



Left view of Tablet

Large cover protects micro SD, audio, USB 3.0, HDMI. Small cover is ethernet



Right view of Tablet

Stylus and external power port



8megapixel Camera



Docking the tablet: insert it straight down and push until the orange rectangle disappears. If not fully docked, you'll carry it by handle and tablet can fall out. Also get in habit of locking the front latch.

